## LifeScience – Cleaning – Clean It! Kit LIQUID FABRIC DETERGENT



 heavy-duty automatic liquid detergent - ready to use - non labelled product recommended dosage: 75 ml/wash -

INGREDIENT	%
LEVENOL® F-200 EMAL® 270D EXCEPARL® LM-LC Palmera® B1210E NaOH (sol. 50%) Sodium Citrate Preservative Comp. 45.1643-1 Antarctico Plus	19.00 7.10 0.90 0.90 Approx. 0.36 3.00 q.s. 0.20
H-JSH (M)	Up to 100%
Deionized Water TECHNICAL CHARACTERISTICS	Up to 100%

- Start the process at room temperature
- Add NaOH to the water and afterwards add Palmera® B1210E (previously melted)
- Adjust the pH (7.0 8.0) with NaOH
- Add LEVENOL® F-200, EXCEPARL® LM-LC, EMAL® 270D and Sodium Citrate
- Continue with the incorporation of optional ingredients
- Final pH adjustment (approx. 8.0 8.5) with NaOH
- Adjust weight with deionized water to 100%

Developed by KAO

Security advice: Cleaning sample formulations are provided herein for illustrative purposes only. Such formulations are not for commercial formulations and have not been subject to comprehensive testing.

Biesterfeld Spezialchemie GmbH Ferdinandstraße 41 20095 Hamburg https://www.biesterfeld.com/de/ Mr. Sergej But Phone: 0049 40 32008 304 E-Mail: household@biesterfeld.com