## LifeScience – Cleaning – Clean It! Kit QUICK DETAILER



• immediate waterbreak • roll-off effect • improves the deep shine of the coating • non labelled product •

INGREDIENT	%
TETRANYL® DM-24	1.00
AMIDET® N	0.20
Preservative	0.08
Deionized Water	Up to 100%

## TECHNICAL CHARACTERISTICS

APPEARANCE SURFACTANT ACTIVE CONTENT pH Color- and odorless liquid 0.69 7.5

## **RECOMMENDED OPERATIVE METHOD**

- Charge water
- Add TETRANYL® DM-24, AMIDET® N and the preservative while stirring

Security advice: Cleaning sample formulations are provided herein for illustrative purposes only. Such formulations are not for commercial formulations and have not been subject to comprehensive testing.

Biesterfeld Spezialchemie GmbH Ferdinandstraße 41 20095 Hamburg https://www.biesterfeld.com/de/

Mr. Sergej But Phone: 0049 40 32008 3004 E-Mail: household@biesterfeld.com